

Product Name: Infant Oral Care Kit
Colours: Bluestone/Blush/Pea Green/Rust/Suva Grey
Dimensions: Silicone Finger Toothbrush - 23 x 23 x 53mm
 Contoured Silicone Toothbrush - 90 x 32 x 16mm
 360° Silicone Toothbrush - 42 x 46 x 126mm
 Cotton Flannel - 188 x 188mm
 Large Storage Case - 156 x 106 x 50mm

Recommended Age: 0 month+

Product Description:

Start teaching your little one important dental hygiene habits with Haakaa's Infant Oral Care Kit! This set includes three different brushes for your baby's teeth as they grow, as well as a cotton flannel and a handy storage case to keep everything in.

Stage 1 Silicone Finger Toothbrush (100% Food-Grade Silicone)

Recommended Age: 0-18 months

Our Finger Brush gets your child used to the sensation of brushing their teeth and gums so that it becomes a fun and essential part of everyday life. The two different surfaces provide options for cleaning delicate new teeth and tender gums - soft bristles or firmer silicone nubs.

Stage 2 Contoured Silicone Toothbrush (100% Food-Grade Silicone)

Recommended Age: 3-24 months

The uniquely shaped Toothbrush is curved to comfortably fit your baby's gum line as they chew down between the bristles. The easy-to-hold non-slip handle is perfect for little hands while the soft silicone bristles clean your baby's teeth from all angles!

Stage 3 360° Silicone Toothbrush (100% Food-Grade Silicone)

Recommended Age: 6-36 months

The soft silicone bristles provide a 360° clean, removing more plaque and give a better overall cleaning experience than conventional children's toothbrushes! Features a safety shield to prevent choking and a handy suction base for hygienic upright storage.


Cotton Flannel (100% Cotton)

Our 100% cotton flannel is gentle on your baby's delicate skin and super absorbent - making washing up your little one easier!

Storage Cases (100% PP)

The large storage case protects against dust and dirt to keep your toothbrushes and flannel clean and hygienic. The ventilation holes at the bottom help to prevent dampness and mould.

Baby Tooth Eruption Order:



Tooth Eruption Chart*

Upper

- 1 8-12 months
- 2 9-13 months
- 3 16-22 months
- 4 13-19 months
- 5 25-33 months

Lower

- 1 6-10 months
- 2 9-13 months
- 3 17-23 months
- 4 14-18 months
- 5 23-31 months

***NOTE:** Baby teeth can come through in any order - this chart depicts a more common pattern. Your baby's teeth may erupt differently to what is shown.

Cleaning and Care:

Clean brushes before and after each use. Although dishwasher safe, we recommend hand washing these products in warm, soapy water and rinsing and drying thoroughly. To sterilise, use a steam steriliser or boil in water for 2-3 minutes. Only soft bristle brushes or soft sponges should be used to clean these products. Do not use bleach-based agents to clean these products. Machine wash the cotton flannel in cold water. Tumble dry low. Do not bleach or iron. Store product in a cool, dry place and avoid direct sunlight. We recommend replacing your child's toothbrush every 3-4 months.

Caution:

For your child's safety, never attach product to cords, ribbons, laces or loose parts of clothing, as it can become wrapped around their neck. Check product condition regularly. Replace if these products show any signs of damage. Do not store near any sharp objects. Hard scourers may scratch the surface. Adult supervision is required at all times. Keep out of reach of children and pets when not in use.



WARNING

Adult supervision is required.

Children can choke on small objects if left unattended.

These products are not toys. Do not use for any other purpose.