



# SILICONE YUMMY POUCH SIPPY SPOUT

## Product Manual English

**Product Name:** Silicone Yummy Pouch Sippy Spout

**Material:** Food-Grade Silicone

**Dimensions:** 73 x 46 x 51mm

**Colours:** Grey/Pea Green

**Recommended Age:** 6 months+

### Product Description:

Let your baby snack anywhere, anytime with the Haakaa Yummy Pouch Sippy Spout! Compatible with all Haakaa Silicone Milk Storage Bags & Pouches for convenient, easy feeding – simply plug the Sippy Spout into the opening of the bag or pouch and squeeze to feed! The variable flow teat allows for safe feeding and drinking and is perfect for baby food, purées and more. It also has an easy-carry loop for taking on-the-go and a dustproof cap to protect from any airborne nasties.

### Features:

- Compatible with Haakaa's range of Silicone Milk Storage Bags & Pouches.
- Perfect for baby food, purées and more!
- Soft yet durable 100% food-grade silicone that's gentle on little mouths.
- X-cut variable flow mouthpiece lets your baby enjoy their food at their own pace.
- Dustproof cap protects from airborne nasties and prevents spills.
- Easy-carry loop for convenient snacking on-the-go.
- BPA, PVC and phthalate-free.

### Cleaning and Care:

Before first use, clean the product then place in boiling water for 5 minutes to sterilise. Wash before and after use. Although dishwasher safe, we recommend disassembling this product and washing in warm soapy water, then rinsing. Only soft bristle brushes or soft sponges should be used to clean this product, as hard scourers may scratch the surface. Do not use any bleach-based cleaners or tablets to sterilise or clean this product. To sterilise, use a steam steriliser or boil in water for 2-3 minutes. Store product in a cool, dry place and avoid direct sunlight.


### Caution:

#### For your child's safety and health


##### WARNING!

- Continuous and prolonged sucking of fluids may cause tooth decay.
- Check product condition regularly. Throw away at the first signs of damage or weakness.
- Keep components not in use out of the reach of children.
- For your child's safety, never attach product to cords, ribbons, laces or loose parts of clothing, as it can become wrapped around their neck.
- Do not store near any sharp objects.
- This product is not a toy. Do not use this product for anything other than its intended use.
- Adult supervision is required.
- Always remove sippy spout and lid when microwave heating.
- Take extra care when microwave heating; localised overheating can occur. Always mix the heated food and check the temperature before feeding.


### Instructions:



Stand the Silicone Yummy Pouch upright and pour contents into the opening.



Plug the sippy spout into the pouch opening. Now simply squeeze the pouch to feed!




For thinner purées, remove the sippy spout and insert the unnotched end of the straw up through the bottom of the X-shaped opening. Once inserted, plug the sippy spout back into the opening.



Cover the spout when not feeding.

### Optional Interchangeable Attachments

Compatible with our range of Silicone Milk Storage Bag & Pouch attachments to grow with your child's needs (sold separately).



**PLEASE NOTE:** This product is an attachment for our range of Silicone Bags & Pouches and will not work by itself.