

AIRTIGHT SILICONE LID GLASS JAR SET

Product Manual

Product Name: Airtight Silicone Lid Glass Jar Set - 210ml (4pcs)

Materials: Food-Grade Silicone, Borosilicate Glass

Dimensions: Silicone Lid - 69 × 69 × 19mm
Borosilicate Glass Jar - 70 × 70 × 92mm

Lid Colours: Assorted/Pea Green

Volume: 7 oz./210ml

Product Description:

Organise your home with Haakaa's Airtight Silicone Lid Glass Jar Set! This set comes with four 210ml borosilicate glass jars, each with its own airtight and leakproof 100% food-grade silicone lid. Each durable borosilicate jar can be safely cleaned in the dishwasher then sterilised in sterilisers or boiling water. The silicone lids seal the jars tightly, keeping your contents fresher for longer. Because of their handy size and strong construction, these jars are incredibly versatile and can be used for a wide range of purposes.

Features:

- A versatile, convenient storage set that can be used for a wide range of purposes.
- Airtight, leakproof lids are made of 100% food-grade silicone.
- Made of high quality borosilicate glass, each jar is crystal-clear and durable.
- Clearly marked measurements on the side of each jar for effortless portioning.
- Wide opening for easy access and cleaning.
- Can be microwave heated or stored in the refrigerator.
- Safe in dishwashers, microwaves, sterilisers and boiling water.
- BPA, PVC and phthalate-free.


Cleaning and Care:

Wash before and after each use. Although dishwasher safe, we recommend hand-washing with a mild dish detergent and rinsing thoroughly. Do not use any bleach-based cleaners or tablets to sterilise or clean your Haakaa products. To sterilise, use a steam steriliser or boil in water for 2-3 minutes, allow to cool completely then dry thoroughly. Store product in a cool, dry place and avoid direct sunlight.


NOTE: The measurements on the jars are printed with food-grade ink. This ink may begin to come off over time if washed with chemical-based detergents. We recommend washing with mild dish soaps only. Only soft sponges should be used to clean this product, as hard scourers may scratch the surface. Avoid vigorously scrubbing this product. To make cleaning easier, rinse jars as soon as possible after use.

Safely Storing and Warming Glass Jar Contents:

Store




Do not fill beyond MAX measurement mark.




Allow hot food to cool before putting on lid and storing in the refrigerator.

Warm



Food can be warmed in the jar by placing into a bowl of warm water, or using a standard bottle warmer on low with the jar lids removed. Check bottle warmer size compatibility first.



Alternatively, **remove lid** and microwave in 30 second increments until warm. Never place jars directly on a stove element or flame.

NOTE: Take extra care when microwave heating; localised overheating can occur. Transfer food to a separate bowl or plate before serving. Always mix the heated food and check the temperature before feeding.

Caution:

- Always use this product with adult supervision.
- Check product condition regularly. Replace if this product shows any signs of damage.
- This product is not a toy - keep out of reach of children and pets.
- Always remove lid when heating or sterilising.
- To avoid dangerous spills, we do not recommend pouring boiling liquids directly into the glass jars.
- Do not forcefully shake the jar while it contains liquids, as this may cause contents to leak.
- Although more durable than standard glass, borosilicate glass may still crack or break if dropped.

PLEASE NOTE: Volume measurements are an approximation and should be used for general reference only.