

haakaa®

GEN. 3 ATTACHMENT RING

PRODUCT MANUAL

English

Product Name: Gen. 3 Attachment Ring

Material: PP

Colours: Peach / Grey

Product Description:

The Haakaa Silicone Baby Bottle Attachment Ring is compatible with all Gen. 3 bottles and attachments. Pass an attachment through the ring and screw onto your bottle to transform it! We have our famous breast pump that lets you express directly into the bottle, a baby bottle to feed your little one expressed milk, a sippy bottle to help your independent toddler transition easily from a bottle to a cup and an airtight container to preserve any leftover food or milk after feeding!


Features:

- Made of safe, non-toxic PP.
- Compatible with all Gen. 3 bottles and attachments.
- Multifunctional design, transform your bottle with just a twist.
- Safe in microwaves, dishwashers, boiling water and steam sterilisers.
- BPA, PVC and phthalate-free.

Cleaning and Care:


Wash before and after each use. Although dishwasher safe, we recommend hand washing in warm soapy water and rinsing and drying thoroughly. Do not use any bleach-based cleaners or tablets to sterilise or clean your Haakaa products. This product can be sterilised with any steam sterilising system or by boiling in water for 2-3 minutes.

Silicone Baby Bottle Diagram



Note: Handle is only compatible with the 8 oz./250ml bottle.

Optional Interchangeable Attachments



Haakaa Silicone Baby Bottles are compatible with all Gen. 3 Silicone Bottle Series attachments.

- a Silicone Bottle Anti-Colic Nipple
- b Silicone Bottle Attachment Ring
- c Silicone Bottle Replacement Cap
- d Silicone Bottle Handle
- e Silicone Bottle Sippy Spout
- f Silicone Bottle Automatic Straw – S/L
- g Silicone Bottle Sealing Disk
- h Silicone Feeding Spoon Head
- i Silicone Breast Pump Flange

Please note: Optional interchangeable attachments each sold separately.

♥ Volume measurements are an approximation and should be used for general reference only.

Instructions



1 Push your chosen attachment through the attachment ring and into place. Ensure the bottom rim of the attachment is laying flat inside the ring.



2 Screw the attachment ring onto the bottle.



3 Compatible with all Haakaa Gen. 3 attachments and bottles.

Caution:

- Check product condition regularly. Replace if this product shows any signs of damage.
- Do not store near any sharp objects.
- Only soft bristle brushes or soft sponges should be used to clean this product. Hard scourers may scratch the surface.
- This product is not a toy. Do not use this product for anything other than its intended use.
- Store product in a cool dry place and avoid direct sunlight.
- Adult supervision is required.